



# 14-DAY Extended Wear Patch


## Application Best Practices



After placement, **PRESS** along the entire edge of the CAM patch (refer to area indicated in red) as firmly as possible for **2 minutes**, working your way down from the top of the patch.



Then, firmly **RUB** along the entire edge of the CAM patch for at least **1 minute**.




Place two fingers under the silver button and firmly press the Recorder against the chest for **15 seconds**.

## Important Tips for Optimal Monitoring



### SKIN PREP

Proper skin prep required to achieve full length of prescribed monitoring duration. Use all 3 prep pads provided and allow skin to completely dry for 2 minutes. Following prep pad scrubbing, a dry gauze may be used to wick up any remaining moisture.



### CONNECTING CAM PATCH

Connect Recorder to CAM patch on a hard, flat surface (such as a table-top) and NOT directly on the chest.



### LOOK FOR LIGHT

Right after connecting Recorder into CAM patch, look for a green light that will blink for 10 seconds.



### AVOID MOISTURE

Refrain from showering or engaging in activity that results in excessive perspiration for at least 24-48 hours after application.

*Please refer to the Quick Reference Instructions for additional application details.*